

DN-S700 Instruction Manual for burning CD-R

1. Please download your target firmware (ISO Recorder) in SDI.

ISORecorder V2 - for Windows XP SP2/SP3 and Windows 2003 (including 64-bit OS)
ISO Recorder V3.1 - for Windows Vista/Windows 7

2. Click the “ISO Recorder Vx” file.




ISORecorder31x86.msi

or




ISORecorderV2RC1.msi

3. Install the “ISO Recorder” in your PC automatically.
4. Download the “PZ**_DNS700_v**.zip” in your PC.
5. Unzip the “PZ**_DNS700_v**.zip” in your PC.
6. Click the “DN-S700 V**.iso” file.
7. The CD Recording Wizard will open in your PC.



8. Click the button.




9. Select the “DN-S700 V**.iso” file, and click the “Open” button.


Insert the Blank CD-R into CD-R recorder.

10. Select the your CD-R Drive.


11. Click the “Next” button.



12. Recording is starting..... Do not touch your PC and CD-Recorder.



CD is burned. Please wait...



13. Click the "Finish" button.



14. Remove the CD-R from CD-Recorder.

15. Please update the firmware of DN-S700 by CD-R.